

Hot or Open Flame Work

Queen's University Building Design Standards

Hot or Open Flame Work/Hot Work Permit

Forward

- 1. The purpose of this procedure is to establish guidelines for safe hot or open flame work in specific campus locations, including residences. Hot or open flame work includes any work that that generates heat and may cause combustion of surrounding materials, including open flame work. Compliance with this policy is the responsibility of the appropriate supervisor and the workers carrying out the procedure.
- 2. **EXCLUSION:** This policy does not apply to shop areas that are designed for this type of work for example, welding shops, and trades shops.

Procedure

- 1. A Hot Work Permit (sample attached) will be obtained from Fix-It and will be filled out whenever hot work is being carried out. The completed form is to be attached to the completed work order or the confined space entry permit as applicable.
- 2. Upon arrival at the work location, ensure that all flammable materials, where practical, are removed from the area where the work is to be carried out. Where this is not practical, isolate the material with a fireproof barrier.
- 3. No work shall be done unless a 5 lb (ABC) dry chemical fire extinguisher is on hand. The worker shall locate where the nearest fire alarm pull station is.
- 4. Check the area for the proximity of heat or smoke detectors. If there is a possibility these may accidentally be triggered, the worker is to arrange for an electrician to deactivate the zone or the detector.
- 5. Prior to the work starting, contact Fixit and advise them:
 - that hot or open flame work is to be carried out.
 - the specific location where the work is being done.
 - confirm that fire extinguisher is on site.
 - indicate whether a smoke/heat detector has been deactivated or a
 - zone deactivated.
 - when the work will commence and the expected time of completion.
- 6. The ERC must also be notified if a fire alarm is being taken out of service.
- 7. The work site is to be checked one hour after the hot work is complete to ensure that there are no hot spots, smoke or other indications of a possible fire in the area around the work site.
- 8. Once the area is found to be safe, the worker must contact Fixit and advise them that:
 - the work is complete.
 - the area has been found to be clear of any possible fires or smoldering debris.
- 9. The ERC is to be notified that the zone or smoke/heat detector has been reactivated.
- 10. Remove all work materials and debris before leaving the site.

Last Updated: July 30, 2024



Hot or Open Flame Work

Queen's University Building Design Standards

- 11. Fixit: When a hot work request is received, record the details of the work on the Fixit board. If an "all clear" has not been received for the hot work by the end of the day, Fixit will contact the worker or the worker's supervisor to confirm that the following:
 - The work is complete.
 - The area is safe, and the fire protection system is in service.

QUEEN'S UNIVERSITY HOT WORK PERMIT

	is permit does not apply to shop areas, which are ding shop, trades shops).	intended	for this	type of work (e.g.:	
Date issued:		(valid for date issued only)			
Loc	eation:				
Des	ecription of work:				
Che	ecklist completed by:				
	PRECAUTIONS TO BE	TAKEN			
	A.A	YES	N/A	COMMENTS	
1.	Rope off area/screen area				
2.	Remove combustible material				
3.	Protect sensitive equipment and surfaces from heat spark damage				
4.	Minimum of 5lb (ABC) dry chemical fire extinguisher hand	on			
5.	Lock out procedure followed				
6.	Lines depressurized				
7.	Confined space procedure followed				
8.	Smoke and heat detectors deactivated				
9.	Fixit notified (before commencement of work) 8:00 ar 4:00 pm 613-533-6757	n			
10.	ERC notified (after hours) 613-533-6111				
11.	Area checked for hot spots or indications of a possible after completion or work.	fire			
12.	Heat detectors (smoke detectors) reactivated.				
13.	Fixit notified (on completion) 613-533-6757				
14.	ERC notified (on completion) 613-533-6111				
Eith	er: Contractor/Company:	oranasa araugunun asuda Albiylada sasar			
Field Representative:			Phone: _		
Or:	Trades Person:	200 (200 (200 (200 (200 (200 (200 (200			

SEND COMPLETED FORM TO FIXIT VIA FAX #613-533-6469

Last Updated: July 30, 2024